Appendices

Contents

APPENDIX 1
1. Minimum System Requirements 1
APPENDIX 2
SC7500 Utility and TWAIN-Driver Installation
1. Location after installation WIN95 2
    Added lines in WIN.INI 2
2. Location after installation WIN3.1X 3
    Added lines in WIN.INI 3
3. Location after installation WIN NT 4.0 4
    Added Lines in WIN.INI 4
4. Location aftere installation DOS 5
5. Location after installation Macintosh 5
APPENDIX 3
1. PPD File Names 7
    PPD Nameing Scheme PC 7
2. PPD Naming Scheme Macintosh 8
3. PDF Files 8
4. WPD Files 8
APPENDIX 4
1. PCL Printer Driver Installation 9
    Printer Driver Installtion WIN95 9
    Printer Driver Installtion WIN3.1x 9
    Added Lines in WIN.INI 10
2. PostScript Printer Driver Installation 10
    Printer Drivers Version Numbers 10
APPENDIX 5
SC7500 Circuit Diagram 11
APPENDIX 6
Jumper Settings for SC7000/Sc7500 Hardware 12
APPENDIX 7
SC7500 Parts List 14

APPENDIX 6

Jumper Settings for SC7500 Hardware

Note: any settings other than Factory Settings are not guaranteed to work.

Gigabyte GA-586ATV Mainboard

JP6,7: CPU Power Select Jumper		
Pin No.	**Function**	**Factory Settings**
Close Pin 1-2	For single 3.3V processor	✓
Close Pin 2-3	For single 2.8V / 3.3V processor (Ex. P55C)	

JP8,9: System Speed Selection			
JP8	**JP9**	**Function**	**Factory Settings**
1-2	1-2	For 50 MHz system speed (CPU 75, 100(x2), PODP 125MHz)	
1-2	2-3	For 60 MHz system speed (CPU 90, 120, 150, 180 MHz)	
2-3	1-2	For 66 MHz system speed (CPU 100, 133, 166, 200 MHz)	✓
2-3	2-3	For 55 MHz system speed (CPU 110 MHz)	

JP11: CPU INT. / EXT. FREQ. RATIO			
1,2	**3,4**		**Factory Settings**
Open	Open	x 1,5	✓
Close	Open	x 2	
Close	Close	x 2,5	
Open	Close	x 3	

PCI-SC200 SCSI-Card

JP1,2: Interrupt Selection			
JP1	**JP2**	**Interrupt**	**Factory Settings**
1-2	Open	A	✓
2-3	Open	B	
Open	1-2	C	
Open	2-3	D	

JP5: On-Card Terminator RJ1, RJ2 Enable/Disable Selection		
JP5	**Function**	**Factory Settings**
Open	Enabled	✓
Close	Disabled	

Seagate ST3851A Hard Disk Drive

Master / Slave Selection		
Pin No.	**Function**	**Factory Settings**
1-2 (C/D) in	Master	✓
1-2 (C/D) out	Slave	
5-6 (Csel) in	Cable select	